



7



8




9



10




11







1




2




3




4




5



6







7









①




②






①



②












③





①

② ADM code







4




5







①




②



3



4





Quick start

secuENTRY HOME
ENTRY 5001 PIN

secu **ENTRY**



Hauptanleitung:
Main manual:
Manuel Principal :
Hoofdgebruiksaanwijzing:



www.burg.biz

BURG-WÄCHTER KG
Altenhofer Weg 15
58300 Wetter, Germany

BD Quick Start ENTRY 5001 PIN HBG/SWI 110322