



Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Pieśe de schimb
/ Rendelhet ő alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
Резервни делови / Atsargini ū dalių / Tellitavad varuosad / Rezervju daļu



Ideal Standard




IOM

A 9237 AA, A 9238 AA

1115 / A866842
(+ A 865 612)




Position

- 1 = A 963 293 NU
- 2 = A 963 285 NU
- 3 = A 963 259 AA
- 4 = EW160NU



Ideal Standard International NV
Corporate Village - Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
www.idealstandardinternational.com





2

