




DIN 1988
Global
Standards


- Ⓧ Montage- und Bedienanleitung
- Ⓜ Installation and operating instructions
- Ⓢ تعليمات التركيب والتشغيل
- Ⓝ 安装及操作指南
- Ⓢ Návod k instalaci a k použití
- Ⓧ Instrucciones de montaje y de manejo
- Ⓧ Instructions de montage et mode d' employ
- Ⓜ ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ ΚΑΙ ΣΥΝΤΗΡΗΣΗΣ
- Ⓧ Szerelési és használati utasítás
- Ⓧ Istruzioni di montaggio e per l'uso
- Ⓜ Montagehandleiding en Gebruiksaanwijzing
- Ⓧ Instrukcja montażu i obsługi
- Ⓧ Instrucțiuni de montaj și utilizare
- Ⓧ Руководство по монтажу и эксплуатации
- Ⓧ Návod na montáž a obsluhu



1.



2.



3.

